

How To Make Beams Look Like Knotty Pine

Following are instructions on how to make a beam look like knotty pine.

Note: If you are staining unfinished timber or unfinished sandblasted beams, you will need to prime them first with Primer.



Primer shown

1.



2.



3.



Pick a desired water based stain for the knot. For this example we used Minwax American Walnut.

Apply the stain over Knot area. Remember to blot off any extra paint with a rag.

After the stain has fully dried, you will need a pine colored stain. For this example we used MinWax English Oak.

4.



5.



6.



Apply the pine colored colored stain to the beam. Remember to gently wipe off any extra stain to desired effect. Lastly, let the beam dry and your done!