

Installing Exterior Window Shutters

Our Polyurethane shutters are easy to install. A good quality PL construction adhesive should be applied to the back. Then they should be bolted (or screwed) directly to the outside face of the house or building. You can easily hide the screw heads with any kind of exterior caulking, or filler.